Huawei OptiXstar EG8147X6-10

Quick Start for QR code

Issue 02

Date 2025-04-10





Copyright © Huawei Technologies Co., Ltd. 2025. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

Trademarks and Permissions

HUAWEI and other Huawei trademarks are trademarks of Huawei Technologies Co., Ltd. All other trademarks and trade names mentioned in this document are the property of their respective holders.

Notice

The purchased products, services and features are stipulated by the contract made between Huawei and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

Huawei Technologies Co., Ltd.

Address: Huawei Industrial Base

Bantian, Longgang Shenzhen 518129

People's Republic of China

Website: https://www.huawei.com

Email: support@huawei.com

Contents

1 Placing the Device	1
2 Connecting Cables	4
3 Indicator Description	7
4 Technical Specifications	9
5 FAOs	10

1 Placing the Device


■ NOTE

- Do not install the ONT and user cables outdoors or in an outdoor cabinet.
- The ONT can be mounted onto a wall or placed on a desk. Do not install the ONT in other modes, such as ceiling.
- Keep 10 cm clearance on all sides to ensure adequate ventilation.
- It is recommended that the computer and ONT be put far away from electric appliances that generate strong magnetic or electric fields, such as microwave ovens.
- When operating optical fibers, pay attention to the operation safety according to the following laser hazard level.



Installing an ONT on the desk

The figure below shows an ONT that is installed on a desk.




■ NOTE

The appearance shown in this document may be different from the actual appearance of the product. The actual product prevails.

Mounting an ONT onto the wall


- 1. Mark two positions with the same spacing as that between the two mounting holes of the ONT using a marker on a wall.
- Select a proper drill bit according to the outer diameter of the screws. Use a
 hammer drill to drill the marked positions on the wall. Then clean the holes
 and install two expansion bolts.
- 3. Use a screwdriver to fasten the screws into the expansion bolts, reserving 8 mm ends out of the wall, and mount the ONT onto the screws.



◯ NOTE

It is recommended that the screw be about 4 mm in diameter and longer than 20 mm. The screw head should be between 6 mm and 9 mm in diameter.

2 Connecting Cables



◯ NOTE

- The fiber connector connected to the optical port on the wall varies depending on actual conditions.
- To ensure normal use of fibers, make sure that the fiber bending radius is larger than 30 mm.

No.	Item	Description	
1	On/Off	Powers the ONT on or off.	
2	Power	Connects to a power adapter.	

No.	Item	Description		
3	USB	Connects to USB storage devices.		
4	TEL	Connects to the ports on a telephone or fax machine.		
5	LAN1-LAN4	Connects to PCs or IP set-top boxes (STBs).		
6	CATV	Connects to a TV.		
7	WLAN/WPS	 When the wireless function (WLAN) is enabled, press the WLAN/WPS switch for 1s to 5s to start Wi-Fi protected setup (WPS) negotiation. When the wireless function (WLAN) is enabled, press and hold the button WLAN/WPS switch for more than 5s to turn off the wireless function (WLAN). When the wireless function (WLAN) is disabled, tap the WLAN/WPS switch for more than 1s to turn on the wireless function (WLAN). NOTE If the WLAN indicator is steady on or blinks, the wireless function is enabled. If the WLAN indicator is off, the wireless function is disabled. 		
8	Reset	Press the button for a short time to reset the device, or press the button for a long time (longer than 10s) to restore the device to the default settings and reset the device. NOTE Reset Huawei ONTs with caution. Otherwise, the ONTs may fail to access the Internet. If an ONT cannot access the Internet after a reset, contact your Internet service provider.		
9	Optical port	The optical port is equipped with a rubber plug and connected to a fiber for upstream transmission. The type of the optical connector connected to the optical port can be SC/APC.		

3 Indicator Description

| \bigcirc |
|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|
| Power | PON | LOS | LAN1 | LAN2 | LAN3 | LAN4 | TEL | USB | WLAN | WPS | CATV |

Indicator	Status	Description		
Power	Steady on	The ONT is powered on.		
	Off	The power supply is cut off.		
PON/LOS	See the followin	g table.		
LAN1-	Steady on	The Ethernet connection is in the normal state.		
LAN4	Blinking	Data is being transmitted on the Ethernet port.		
	Off	The Ethernet connection is not set up.		
TEL	Steady on	The ONT is registered with the softswitch but no service flows are transmitted.		
1 1 7	Blinks twice a second	The ONT is registered with the softswitch, and data is being transmitted on the port.		
	Blinks once every 2 seconds	The ONT fails to be registered with the softswitch.		
	Off	The POTS port is disabled.		
USB	Steady on	The USB port is connected and working in the host mode, but no data is transmitted.		
	Blinking	Data is being transmitted on the USB port.		
	Off	The system is not powered on or the USB port is not connected.		
WLAN	Steady on	The WLAN function is enabled.		
	Blinking	Data is being transmitted on the WLAN port.		

Indicator	Status	Description	
	Off	The WLAN function is disabled.	
WPS	Steady on	The WPS function is enabled.	
	Blinking	A Wi-Fi terminal is accessing the system.	
	Off	The WPS function is disabled.	
CATV	Steady on	The CATV function is enabled and CATV signals are received.	
	Off	The CATV function is disabled or CATV signals are not received.	

Status No.	PON Status	LOS Status	Description
1	Off	Off	The ONT is prohibited by the upper-layer
2	Blinks twice a second	Blinks twice a second	device or blinks abnormally. Contact the service provider for help.
3	Blinks twice a second	Off	The ONT attempts to set up a connection with its upper-layer device.
4	Steady on	Off	A connection is set up between the ONT and its upper-layer device.
5	Off	Blinks once every 2 seconds	The ONT is not connected to fibers or does not receive optical signals.
6	Blinks once every 2 seconds	Blinks once every 2 seconds	The hardware is faulty.

If the ONT is not powered on or the power switch is turned off, all indicators are off.

4 Technical Specifications

Product	Function
Huawei OptiXstar	4 Ethernet ports
EG8147X6-10	1 POTS port
	1 USB port
	• 1 CATV
	• 2.4 GHz & 5 GHz Wi-Fi 6

- Power adapter input: See the nameplate on the adapter
- System power supply: See the nameplate on the device
- Ambient temperature: 0°C to +40°C
- Ambient humidity: 5%–95% (non-condensing)
- Dimensions (H x W x D): 32 mm x 195 mm x 120 mm
- Weight: About 305 g
- Maximum system power consumption: 18 W

5 FAQS

■ NOTE


The following web page is only for reference. The actual web page of the product prevails.

How do I log in to the Huawei ONT web page?

Ⅲ NOTE

You are advised to use the latest browser to log in to the web configuration page. Chrome 58/Edge 14/Firefox 54/Safari 10/Opera 55 or later is recommended. If the browser of an earlier version is used, compatibility issues may occur.

- Wireless login
- 1. Connect your mobile phone, pad, or PC to the Wi-Fi network of the Huawei ONT.
- 2. Enter the IP address in the address box of a browser and press **Enter**. On the displayed login page, enter the username and password. (For details about the IP address, login username, and password, see the product nameplate.)
- Wired login
- Use a network cable to connect a PC to the Huawei ONT.



2. Set the IP address of the PC in the same subnet as the web address of the Huawei ONT. For example, if the web address of the Huawei ONT is 192.168.a.b (for the web address of the Huawei ONT, see the product nameplate), set the IP address of the PC to 192.168.a.c.

Ⅲ NOTE

The preceding cable connection diagram and login pages are only for reference, and those of the actual product prevail.

3. Log in to the web configuration page.


- a. Open a browser. In the address box, enter the web address (printed on the nameplate of the Huawei ONT). Press **Enter**.
- b. Enter the login user name and password (printed on the nameplate of the Huawei ONT). Click **Log In**.

■ NOTE

- If you do not perform any operations after logging in to the system within five minutes, you will be logged out, and the system automatically returns to the login interface.
- The system will be locked for one minute if you input incorrect user name and password for three consecutive times.
- Change the initial password after logging in to the web page for the first time.


How do I change the Wi-Fi password?

- Log in to the Huawei ONT web page using your mobile phone, pad, or PC. For details, see "How do I log in to the Huawei ONT web page?"
- Choose the Advanced > WLAN tab and choose 2.4G Basic Network Settings.
 (If you want to configure 5GHz Wi-Fi, choose 5G Basic Network Settings.)




What can I do if I forget the Wi-Fi password?

- 1. Log in to the Huawei ONT web page using your PC by wired login. For details, see "How do I log in to the Huawei ONT web page?"
- Choose the Advanced > WLAN tab and choose 2.4G Basic Network Settings.
 (If you want to configure 5GHz Wi-Fi, choose 5G Basic Network Settings.)



What can I do if I cannot connect to the Wi-Fi network?



How to improve the Wi-Fi speed of a Huawei ONT?

- 1. Wi-Fi speed relies on the bandwidth provided by the ISP, so the simplest way is to upgrade to faster broadband.
- 2. Wi-Fi speed is affected by the Wi-Fi signal strength and quality.
- 2.1 Determine the deployment positions of ONT based on house structures, indoor obstacles, and electrical appliance-caused interferences. If possible, put ONT in the middle of a planned coverage area and ensure that no obstacles exist and they are placed at high positions for better coverage. In addition, ensure that the ONT is far away from interference sources such as TVs, refrigerators, cordless phones, and Bluetooth devices.
- 2.2 Note that load-bearing walls, floors, and metal coated glass may block Wi-Fi signals, avoid or reduce these obstacles between the ONT and Wi-Fi devices (such as pads, mobile phones, and laptops). For outdoor yards, large balconies, and compound rooms, etc., it is recommended to add repeaters to enhance the Wi-Fi coverage.
- 2.3 For common places where users access the Internet, such as a living room, study room, or master room, pre-evaluate whether their signal strength is strong enough. If the signal strength is insufficient (Generally, lower than -72dBm), it is

recommended to adjust ONT positions or add new repeaters to enhance the Wi-Fi coverage.

- 3. Using the correct radio channel. Generally, the Huawei ONT automatically selects the optimal channel. If the network is slow or the quality turns poor from time to time, you can use a Wi-Fi scanner such as Wi-Fi Stumbler or Wi-Fi Analyzer to search for the optimal channel.
- 4. To prevent unauthorized network access, log in to the web interface of the router and select MAC address filtering based on your requirements.

What can I do if the network speed is slow?

- 1. Check whether network cables are properly connected. Remove and then insert the network cables. Then, check whether the network speed is normal.
- Check whether downloading, network video watching, or other operations occupy a large amount of bandwidth. Due to bandwidth restrictions, if some network applications occupy a large amount of network bandwidth, the network speed is slow.
- 3. Use another PC, mobile phone, or pad to check whether the network speed is normal.

A phone does not ring upon an incoming call but communication is in normal state when the phone is in off-hook state.

The ONT supports a maximum of 60 V AC ringing current voltage. Check whether the ringing current voltage of the phone is higher than 60 V AC. If it is higher than 60 V AC, replace the phone.

How do I restore the Huawei ONT to factory setting?

Press **Reset** by using a needle-type object for longer than 10s to restore factory defaults and reset the Huawei ONT. If the indicator is off and then is lit, the system restarts successfully.



Exercise caution when restoring factory settings. This function may cause the loss of ONT configuration information and further cause an Internet access failure. If this problem occurs, contact your service provider for help.

How can I download Huawei ONT firmware or software?

Huawei ONT is used with an OLT and NMS of a required version. If the versions are not the required ones, the ONT may not work.

If required, contact your internet service provider to obtain the correct ONT firmware or software.